



Start the preparation of FZOHBMUK by removing the cable from the messenger wire. To simplify the separation between the messenger wire and the cable we have made a constriction in the plastic web. To prevent damage to the sheath, we recommend that you pull the messenger wire as shown in the picture. Alternatively use a special tool.



Measure and mark the length of the cable to be opened up. The length is determined by the splice box that you intend to install the cable in. See installation instructions for the box you have chosen. For example 1.5 m, when using Nexans splice box NS2.




Make a ring cut on the cable sheath at the mark.

Remove 10 cm of the sheath to expose the cable body and ripcord. We recommend that you always use the ripcord to remove the sheath. Make a small cut in the sheath with a wire cutter or sharp knife. Wrap the ripcord around the jaws on a plier.



Put the ripcord in the small cut and pull it through the sheath. Keep the ripcord along the cable when opening the sheath.



Remove the sheath and cut all the yarns and tapes lying around the fiber tubes. Unwrap the fiber tubes from the reinforcing member (FRP) and cut off the FRP in an appropriate length.



Ring cut the tube with a tool which is intended for the purpose. Applying wrong tools can damage the fibers. The length to be opened in this operation is determined by the splice box that you intend to use.

